

INNOCENTI MINI COOPER 1300 EXPORT DIAGRAM 2NB030

REDRAWN BY
MICHAEL LUTTRELL
DAYTON TEXAS
AKA
MIKE L
ON <http://www.theminforum.co.uk/forums/>
Re-Edit by:
MARCUS WIMMER aka MINIKIN
Added actual cable colours, parts list and fuse box and connections

THE DRAWING USED WAS FOUND AT:
<http://www.minimotor.com/index.htm>
FILE NAME: WD_InnoCooper1300EX.pdf

SHEET SIZE IS:
DIN A0 = 1189x841mm at 100%
AT 100%

- | | |
|------------|-------------------|
| B...Black | UW...Blue-White |
| U...Blue | YB...Yellow-Black |
| N...Brown | NB...Brown-Black |
| G...Green | EB...Grey-Black |
| P...Purple | GB...Green-Black |
| R...Red | WB...White-Black |
| W...White | RB...Red-Black |
| Y...Yellow | UB...Blue-Black |
| E...Grey | |
| O...Orange | |

WHEN A CABLE HAS TWO COLOUR CODE
LETTERS THE FIRST DENOTES THE MAIN COLOUR
AND THE SECOND DENOTES THE TRACER COLOUR.

- 1 Proiettori
- 2 Fanali anteriori
- 3 Ripetitori laterali
- 4 Trombe
- 5 Distributore
- 6 Bobina A.T.
- 7 Alternatore
- 8 Termistore
- 9 Motorino avviamento
- 10 Interruttore luci di retromarcia
- 11 Interruttore luci arresto
- 12 Interruttore per spia freno a mano
- 13 Relè trombe
- 14 Relè avviamento
- 15 Motorino tergicristallo due
- 16 Interruttore doppio circuito freno
- 17 Termometro acqua
- 18 Amperometro
- 19 Manometro olio
- 20 Contagiri - Spie luci e fari
- 21 Tachimetro - spie: generatore e direzione
- 22 Livello carburante con spia riserva
- 23 Elettropompa lavavetro
- 24 Devioluci
- 25 Relè intermittenza
- 26 Portafusibili
- 27 Interruttore accensione e avviamento
- 28 Interruttore luci esterne
- 29 Commutatore tergicristallo
- 30 Interruttore elettropompa lavavetro
- 31 Interruttore luci quadro
- 32 Interruttore lunotto termico
- 33 Interruttore elettroventilatore
- 34 Motorino elettroventilatore
- 35 Accendisigari
- 36 Spia doppio circuito freni
- 37 Interruttore porta sinistra
- 38 Piafoniera
- 39 Interruttore porta destra
- 40 Comando livello carburante e riserva
- 41 Pompa elettrica alimentazione
- 42 Batteria
- 43 Fanali posteriori sinistra e destra e luci di retromarcia
- 44 Fanale targa
- 45 Lunotto termico
- 46 Commutatore luci direzione
- 47 Interruttore trombe

- 1 Front lights
- 2 Side lights & indicators
- 3 Side repeaters
- 4 Horn
- 5 Distributor
- 6 HT coil
- 7 Alternator
- 8 Temperature sensor
- 9 Starter motor
- 10 Reverse light switch
- 11 Brake light switch
- 12 Hand brake light switch
- 13 Horn relay
- 14 Starter relay
- 15 Two speed wiper motor
- 16 Double circuit switch brake
- 17 Water thermometer
- 18 Ammeter
- 19 Oil pressure gauge
- 20 Tachometer - Warning lights and headlights
- 21 Speedometer - lights: generator & direction
- 22 Fuel level with reserve warning light
- 23 Electric screen washer pump
- 24 Head lamp dip switch
- 25 Direction indicator relay
- 26 Fuse holder
- 27 Ignition and starter switch
- 28 External light switch
- 29 Wiper switch
- 30 Electric screen washer pump switch
- 31 Panel light switch
- 32 Heated rear window switch
- 33 Electric fan switch
- 34 Electric fan motor
- 35 Cigar lighter
- 36 Double brake circuit warning light
- 37 Left door switch
- 38 Ceiling light
- 39 Right door switch
- 40 Fuel and reserve level sender
- 41 Screen washer pump
- 42 Battery
- 43 Left and right taillights and reversing lights
- 44 License plate light
- 45 Rear window defroster
- 46 Indicator switch
- 47 Horn button

- 1 Front lights
- 2 Side lights & indicators
- 3 Side repeaters
- 4 Horn
- 5 Distributor
- 6 HT coil
- 7 Alternator
- 8 Temperature sensor
- 9 Starter motor
- 10 Reverse light switch
- 11 Brake light switch
- 12 Hand brake light switch
- 13 Horn relay
- 14 Starter relay
- 15 Two speed wiper motor
- 16 Double circuit switch brake
- 17 Water thermometer
- 18 Ammeter
- 19 Oil pressure gauge
- 20 Tachometer - Warning lights and headlights
- 21 Speedometer - lights: generator & direction
- 22 Fuel level with reserve warning light
- 23 Electric screen washer pump
- 24 Head lamp dip switch
- 25 Direction indicator relay
- 26 Fuse holder
- 27 Ignition and starter switch
- 28 External light switch
- 29 Wiper switch
- 30 Electric screen washer pump switch
- 31 Panel light switch
- 32 Heated rear window switch
- 33 Electric fan switch
- 34 Electric fan motor
- 35 Cigar lighter
- 36 Double brake circuit warning light
- 37 Left door switch
- 38 Ceiling light
- 39 Right door switch
- 40 Fuel and reserve level sender
- 41 Screen washer pump
- 42 Battery
- 43 Left and right taillights and reversing lights
- 44 License plate light
- 45 Rear window defroster
- 46 Indicator switch
- 47 Horn button

