

KEY TO THE WIRING DIAGRAM - 1988

ON

No. Description

Grid
reference

1. Battery	A1	12. L.H. tail lamp - non U.K. markets	C5	105. Automatic transmission inhibitor switch	B1
2. Lighting switch - main - split lighting circuit - Germany only	B3	12. L.H. tail lamp - U.K. markets only	B4	107. Coolant thermistor	C4
2. Lighting switch - main - non U.K. markets	C5	13. Horn - U.K. markets only	A4	114. Oil pressure switch	C4
2. Lighting switch - U.K. markets only	A4	13. Horn - non U.K. markets	C5	115. Brake fluid level switch	A2
3. Headlamp dipswitch - non U.K. markets	C5	14. Horn switch - U.K. markets only	A4	119. Ignition warning light	C4
3. Headlamp dipswitch - U.K. markets only	A4	14. Horn switch - non U.K. markets	B5	120. Oil pressure warning light	B4
4. Headlamp dip beam - non UK markets	C5	15. Direction indicator switch	C2	123. Tachometer	B4
4. Headlamp dip beam - UK markets only	B4	16. R.H. front direction indicator lamp	C2	124. Coolant temperature gauge	B4
5. Headlamp main beam - non U.K. markets	C5	17. L.H. front direction indicator lamp	A3	125. Fuel gauge	B4
5. Headlamp main beam U.K. markets only	B4	18. Heater switch	A3	128. Panel lights	B4
6. R.H. sidelamp - Germany only	C3	19. Heater motor	C6	130. Main beam warning light	C4
6. R.H. sidelamp - non U.K. markets	C5	20. Windscreen wiper motor	A1	131. L.H. indicator warning light	C4
6. R.H. sidelamp - U.K. markets only	C5	21. Ignition switch	A4	132. R.H. indicator warning light	B4
7. L.H. sidelamp - Germany only	C3	22. Headlamp flash switch - U.K. markets only	C5	149. Interior light	A2
7. L.H. sidelamp - non U.K. markets	C5	22. Headlamp flash switch - non U.K. markets	A3	173. Radio - single speaker	A5
7. L.H. sidelamp - U.K. markets only	B4	23. Reverse lamp switch	A2	173. Radio/cassette player	A5
8. Number plate illumination lamps - Germany only	C3	24. Rear fog lamp switch	B2	174. R.H./single front door speaker	B5
8. Number plate illumination lamps - non U.K. markets	C5	27. Direction indicator unit	B2	175. L.H. front door speaker	B5
8. Number plate illumination lamps - U.K. markets only	B4	27. Hazard warning unit	B2	265. L.H. stop light	B3
9. R.H. tail lamp - Germany only	C3	29. Windscreen washer motor	C6	266. R.H. stop light	B3
9. R.H. tail lamp - Non U.K. markets	C5	31. Heated rear window switch	A3	284. Fusebox	A1, A4, B1, C3, C5
9. R.H. tail lamp - U.K. markets only	B4	32. Heated rear window element	B3	288. Rear fog lamp	B2
10. Stop lamp switch	A3	33. Hazard warning light	C2	293. Dim/dip relay	A4/A5
12. L.H. tail lamp - Germany only	C3	34. Hazard warning switch	C2	344. L.H. reversing lamp	B3
		57. L.H. side repeater lamp	C2	345. R.H. reversing lamp	B3
		58. R.H. side repeater lamp	C2	391. Distributor	A1
		59. R.H. front door switch	B2	399. Fog rearguard warning light	A2
		60. L.H. front door switch	B2	419. In-line fuse	A2, A5, B1, C3
		66. Wash/wipe switch	C6	424. R.H. rear direction indicator light	C2
		68. Dim/dip resistor	A4	425. L.H. rear direction indicator light	C3
		80. Alternator	A1	426. Voltage stabilizer	B4
		81. Starter motor/solenoid	A1	427. Heated rear window warning light	B3
		82. Starter relay	A1	428. Brake failure light test switch	A2
		83. Ignition coil	A1	429. Emission control valve switch	A3
		100. Ballast resistor	A1	430. Vacuum solenoid valve	B3
		102. Fuel tank sender unit	C4		