

Wiring diagram 21 - Engine management circuit (fuel-injected models)

F to Wiring diagram 20
M to Wiring diagram 20
S to Wiring diagram 22
T to Wiring diagram 22